

TOP VIEW

SIDE VIEW

NOTES:

DEPTH & DIAMETER OF SKIRT BELOW BASE OF NUT IS NOT CRITICAL

REMOVE SQUARE GATE VALVE WRENCH NUT FROM VALVE STEM AND REPLACE W/PENTAGON NUT.

MATERIAL: CAST IRON OR DUCTILE IRON

REVISION	BY	DATE	CK